
























Code	Size	Pack	Price	Unit	Code	Size	Pack	Price	Unit
<b>LEGS Anchor Powers®</b> <i>Wallboard Anchor</i> 					<b>STRAP TOGGLES Powers®</b> <i>Wallboard Anchor UNC/BSW</i> 				
BLA1		100	N/A	100	BST316	3/16 UNC	100	N/A	100
<b>WALL DOG Anchor Powers®</b> <i>Chrome Plated</i> 					<b>SPRING TOGGLE Anchor</b> <i>Round Head Screw</i> 				
<i>All Steel One Piece-No Plug Required</i>					<b>BSTR182</b> 1/8x2 100 N/A 100				
BWALLDOG	5 x 38	100	N/A	Pk100	<b>BSTR183</b> 1/8x3 100 N/A 100				
<b>PLASTIC POLY TOGGLE Anchors</b> <i>Plasterboard-Gypsum</i> 					<b>BSTR3162</b> 3/16x2 100 N/A 100				
<b>BPT0803</b>	8.0x3	100	N/A	100	<b>BSTR3163</b> 3/16x3 100 N/A 100				
<b>BPT0810</b>	8x10-13	100	N/A	100	<b>BSTR3164</b> 3/16x4 100 N/A 100				
<b>BPT0813</b>	8x13-16	100	N/A	100	<b>SPRING TOGGLE Anchor</b> <i>Csk Head Screw</i> 				
<b>BPT0816</b>	8x16-20	100	N/A	100	<b>BSTC3163</b> 3/16x3 100 N/A 100				
<b>HOLLOW WALL Anchors</b> 					<b>BSTC3164</b> 3/16x4 100 N/A 100				
<b>BHWA4XS</b>	1/8 4-5	100	N/A	100	<b>SPRING TOGGLE Anchor</b> <i>Cup Hook Screw</i> 				
<b>BHWA4S</b>	1/8 10-12	100	N/A	100	<b>BSTCH3163</b> 3/16x3 100 N/A 100				
<b>BHWA4SL</b>	1/8 3-16	100	N/A	100	<b>SPRING TOGGLE Anchor</b> <i>Square Shoulder Hook Screw</i> 				
<b>BHWA4L</b>	1/8 16-24	100	N/A	100	<b>BSTSH3163</b> 3/16x3 100 N/A 100				
<b>BHWA4XL</b>	1/8 32-36	50	N/A	100	<b>HOLLOW WALL Anchor</b> <i>Setting Tools</i> 				
<b>BHWA6S</b>	3/16 10-16	50	N/A	100	<b>BHWST1</b> Pistol 1 N/A Each				
<b>BHWA8S</b>	1/4 10-12	50	N/A	100	<b>BHWST2</b> Plier 1 N/A Each				
<b>HOLLOW WALL Anchors</b> <i>Hammer Drive</i> 					<b>Vertig®</b> <i>Vertical Hanger</i> 				
<b>BHWA4SD</b>	1/8 10-12	100	N/A	100	<b>Vertig®</b> <i>Side Hanger</i> 				
<b>Vertig®</b> <i>Vertical Hanger</i> 					<b>Vertig®</b> <i>Side Hanger</i> 				
<i>Self Drilling For Steel- Vertical Applications</i>					<i>Self Drilling For Steel Horizontal Application</i>				
<i>M6 Female Threaded Head</i>					<i>M6 Female Thread Head #28096</i>				
<b>BVMM06V25</b>	1/4-20x25	100	N/A	100	<b>BVMM06S25</b>	1/4-20x25	100	N/A	100
<i>M8 Female Threaded Head with Hex Nuts</i>					<i>M8 Female Thread Head with Hex Nuts #28112</i>				
<b>BVMM08V25N</b>	1/4-20x25	100	N/A	100	<b>BVMM08S25N</b>	1/4-20x25	100	N/A	100
<i>M10 Female Threaded Head with Hex Nuts</i>					<i>M10 Female Thread Head with Hex Nuts #28100</i>				
<b>BVMM10V25N</b>	1/4-20x25	100	N/A	100	<b>BVMM10S25N</b>	1/4-20x25	100	N/A	100
<b>Vertig®</b> <i>Vertical Hanger</i> 					<b>Vertig®</b> <i>Side Hanger</i> 				
<i>Type 17 Point For Timber- Vertical Applications</i>					<i>Type 17 Point For Timber- Vertical Applications</i>				
<i>M6 Female Threaded Head #28125</i>					<i>M6 Female Threaded Head</i>				
<b>BVWM06V50</b>	1/4x25	100	N/A	100	<b>BVWM10S50</b>	1/4x50	100	N/A	100
<i>M8 Female Threaded Head #28060</i>					<b>Vertig®</b> <i>Vertical Hanger</i> 				
<b>BVWM08V50</b>	1/4x50	100	N/A	100	<b>CONCRETE - Vertical Applications</b>				
<i>M10 Female Threaded Head #28044</i>					<i>M6 Female Threaded Head #28080</i>				
<b>BVWM10V50</b>	1/4x50	100	N/A	100	<b>BVCM06V32</b>	6.5x32	100	N/A	100
<i>M10 Female Threaded Head #28125</i>					<i>M10 Female Threaded Head #28084</i>				
<b>BVWM10V25</b>	1/4x25	100	N/A	100	<b>BVCM10V38</b>	6.5x38	100	N/A	100
<b>Vertig®</b> 					<b>Vertig®</b> <i>Drive Sockets</i> 				
<i>Universal Socket Driver SDS &amp; T17 Pt VERTIGO</i>					<i>Socket Drivers CONCRETE VERTIGO-Blue</i>				
<b>BVUS</b>	RED	5	N/A	Each	<i>Suit M6 Female Threaded Head #7195</i>				
<b>Vertig®</b> 					<b>BVCM06DSKT</b> M6 BLUE 5 N/A Each				
<i>Tie Wire Head Purlin Screw 50mm Total Length</i>					<i>Suit M10 Female Threaded Head #7197</i>				
<i>For Single Purlin 1.2mm - 1.6mm #TWPS</i>					<b>BVCM10DSKT</b> M10 BLUE 5 N/A Each				
<b>BVTWPS</b>	1/4-14x22	1000	N/A	100	<b>VERTIGO 3000</b> 				
<i>Socket Driver Suit TWPS</i> 					<i>SDS TOOL for Concrete Vertigo Anchors</i>				
<b>BVTWPSDSKT</b>	SOCKET	5	N/A	Each	<b>BVCSDS</b>		1	N/A	Each